

CARGO CABINETS M-LC

Merianto Medical hospital furniture includes **M-LC** cargo cabinets which are high-capacity front opening tall cabinets. The cabinet interior is transported on strong ball-bearing runners and can be opened up to 100%. The cabinet interior consists of special adjustable inner shelves, and the cabinet can accommodate up to 12 shelves. The inner shelf frame is made of aluminium to which different label holders and dividers may be attached.



The cargo cabinet is made from quality melamine. The selection includes cabinet widths of 300 mm, 400 mm or 500 mm. The cabinet has interior LED lighting. The load capacity of the inner shelves is 15 kg per shelf, and the total load capacity of the cabinet is 150 kg.

- The cabinet cargo system features soft-close operation.
- The cabinets are mounted on a closed plinth or on an open metal frame.
- It is possible to equip the cabinets with tops that are angled; this assists in avoiding dust collecting on the top surface.
- The cabinet is lockable.
- The cabinet façade options also include a glass door with an aluminum frame.
- The inner shelves used in the cabinet have many additional accessories, dividers, label holders etc. which help create order and save space
- The base options for the inner shelves are: white plastic, transparent acrylic glass, tempered glass, metal mesh, and an inner shelf with hanging hooks for various accessories such as scissors, etc.

Standard options include five different finishings:



It is also possible to select from a wider variety of different colours and finishes from the catalogues of melamine producers, the availability of which must be verified at the time of ordering.

DESCRIPTION		Width	Depth	Height
		mm.	mm.	mm.
Cargo cabinet	M-LC3	300	670	2100
Cargo cabinet	M-LC4	400	670	2100
Cargo cabinet with glass door	M-LC4-KL	400	670	2100
Cargo cabinet	M-LC5	500	670	2100
Cargo cabinet with glass door	M-LC5-KL	500	670	2100